Pipe Spike

Installation Instructions

PS25•PS38

*Not Recommended for use in overhead applications

Installation Procedure

Drill a hole into the base material to a depth of at least 1/2" deeper than the embedment required. The tolerances of the drill bit used should meet the requirements of ANSI Standard B212.15. Blow the hole clean of dust and other material.



Where a fixture is used, drive the anchor through the fixture into the anchor hole until the head is firmly seated against the fixture. Be sure the anchor is driven to the required embedment depth. The Tie-Wire and Pipe Spike versions should be driven in until the head is seated against the surface of the base material.



